

Prolific USB Serial Adapter

Installation Guide

This guide contains installation instructions for the following operating systems:

1. [Windows](#)

Prolific USB Serial Adapter

Installation for Windows

Install Guide

To install the driver:

Prior to installing this device, ensure that your operating system is up to date (for example, you have installed the most recent service pack).

1. Right-click the zip folder that you downloaded, select **Extract All**, and follow the on-screen instructions.
2. In the list of extracted files, right-click the **Setup.exe** file and select **Run as Administrator**.

Note: If the **Run as Administrator** option is not available, you might be attempting to run the installer from within the zipped file. Extract the files using the instructions in Step 2.

3. Follow the on-screen prompts to install the device drivers and restart the computer when prompted.
4. Once Windows has restarted, connect the USB serial adapter to your computer.
5. Your computer will automatically complete the driver installation and your device should be ready to use.

Note: If you receive a driver signature error when trying to install these drivers please visit our Support site at <http://www.startech.com/Support>